



TOP VIEW



SIDE VIEW



NOTES:

- A: 8-32 clearance through part with \varnothing 0.313" counterbore, 0.164" deep.
- B: \varnothing 0.350" flat-bottom pocket to accept wire feedthrough rod (see assembly drawing). Depth not important, but rod must be snug.

ADDITIONAL NOTES:

1. Material is Delrin (any color). Starting block is 2.125" x 1.75" x 1.375".
2. Standard tolerance is 0.005" unless otherwise noted. Holes should match up with isolator mold.
3. Cut holes A first and use them to secure part in CNC machine
4. Fillets are drawn as \varnothing 0.5", but their accuracy and detail are unimportant.

LONG LASER SILICONE MOLD -- FIBER MOLD

P. MARTIN

03/08/12